



## **3 X 1 Bash Guards Installation Instructions**

- Step 1:** Remove bolts from chainring
- Step 2:** Replace bolts with the supplied bolts (it is recommended to put lube on bolts)
- Step 3:** Face the spacer portion of the bolt out from the bike
- Step 4:** Remove center screw and tighten bolts
- Step 5:** Slide bash guard over crank and align with bolts
- Step 6:** Screw in bolts until tight
- Step 7:** Adjust front derailleur to clear bash guard

If you have any questions call 1-866-758-9696