



Accessory Mount Installation Instructions

- Step 1:** Remove headset screw with an Allen wrench then remove headset cap
- Step 2:** Depending upon clearance between accessory mount and stem attach your light or computer to the mount before securing it to the bike
- Step 3:** Secure accessory mount to bike under headset cap
- Step 4:** Align w/ stem and tighten headset screw to approx. 22 inch/lbs -
Do Not Over Tighten
- Step 5:** Attach your accessory to accessory mount if not done earlier

If you have any questions call 1-866-758-9696