



Ultra Lite, Carbon & Threadless Headset Cap Installation Instructions

- Step 1:** Remove headset screw with Allen wrench
- Step 2:** Remove existing headset cap
- Step 3:** Place new custom headset cap on top of stem
- Step 4:** Reinstall screw (apply lube to screw if needed)
- Step 5:** Tighten headset screw to approx. 22 inch/lbs - Do Not Over Tighten

If you have any questions call 1-866-758-9696