



## Rear Brake Reservoir Cover Installation Instructions

- Step 1:** Remove existing rear brake reservoir cover by removing screws
- Step 2:** Keep any OEM plastic/rubber gaskets or inserts
- Step 3:** Use caution to not drip brake fluid onto bike
- Step 4:** Align new rear reservoir cover to correct position while using the before mentioned gaskets/inserts
- Step 5:** Reuse old screws or use supplied screws to tighten down – *Tighten To Manufacturer's Torque Specifications.*

If you have any questions call 1-866-758-9696