



## **Standard Bash Guards Installation Instructions**

- Step 1: Remove chainring bolts from chainring
- Step 2: Remove large outer chainring
- Step 3: Replace outer chainring with bash guard (line up with holes)
- Step 4: Replace chainring bolts and tighten (it is recommended to put lube on bolts)
- Step 5: Make sure front derailleur clears bash guard for shifting (adjust if needed)

If you have any questions call 1-866-758-9696